

# ELATION PARAGON S - DMX TRAITS

Features subject to change without notice

| MODE/CHANNEL |          |         | FUNCTION                               | SNAP | DEFAULT VALUE |
|--------------|----------|---------|----------------------------------------|------|---------------|
| STANDARD     | EXTENDED | VALUES  |                                        |      |               |
| 1            | 1        | 0-255   | <b>Pan</b><br>Left → Right             |      | 127           |
| 2            | 2        | 0-255   | <b>Pan Fine</b><br>Fine position       |      | 127           |
| 3            | 3        | 0-255   | <b>Tilt</b><br>Forward → Backward      |      | 127           |
| 4            | 4        | 0-255   | <b>Tilt Fine</b><br>Fine position      |      | 127           |
| 5            | 5        | 0-255   | <b>Cyan</b><br>0 → 100                 |      | 0             |
|              | 6        | 0-255   | <b>Cyan Fine</b><br>Fine saturation    |      | 0             |
| 6            | 7        | 0-255   | <b>Magenta</b><br>0 → 100              |      | 0             |
|              | 8        | 0-255   | <b>Magenta Fine</b><br>Fine saturation |      | 0             |
| 7            | 9        | 0-255   | <b>Yellow</b><br>0 → 100               |      | 0             |
|              | 10       | 0-255   | <b>Yellow Fine</b><br>Fine saturation  |      | 0             |
| 8            | 11       | 0-255   | <b>CTO</b><br>Cold → Warm              |      | 0             |
|              | 12       | 0-255   | <b>CTO Fine</b><br>Fine saturation     |      | 0             |
| 9            | 13       |         | <b>CRI</b>                             |      | 127           |
|              |          | 0-126   | CRI 73 - 80                            |      |               |
|              |          | 127     | CRI 80 (Highest Output)                |      |               |
|              |          | 128-255 | CRI 80 - 93                            |      |               |
| 10           | 14       |         | <b>Color</b>                           |      | 0             |
|              |          | 0-15    | Open                                   |      |               |
|              |          | 16-31   | Red                                    |      |               |
|              |          | 32-47   | Blue                                   |      |               |
|              |          | 48-63   | Purple                                 |      |               |
|              |          | 64-79   | Green                                  |      |               |
|              |          | 80-95   | UV                                     |      |               |
|              |          | 96-111  | Quad Color                             |      |               |
|              |          | 112-127 | CTB                                    |      |               |
|              |          |         | <b>Scroll</b>                          |      |               |
|              |          | 128-189 | Clockwise, fast → slow                 |      |               |
|              |          | 190-193 | Stop                                   |      |               |
|              |          | 194-255 | Counter-clockwise, slow → fast         |      |               |
|              | 15       |         | <b>Color Fine</b>                      |      | 0             |
|              |          | 0-255   | Position                               |      |               |

# ELATION PARAGON S - DMX TRAITS

Features subject to change without notice

| MODE/CHANNEL |          |         | FUNCTION                                 | SNAP | DEFAULT VALUE |
|--------------|----------|---------|------------------------------------------|------|---------------|
| STANDARD     | EXTENDED | VALUES  |                                          |      |               |
| 11           | 16       |         | <b>Rotating Gobo</b>                     | X    | 0             |
|              |          | 0-9     | Open                                     |      |               |
|              |          | 10-19   | Gobo 1                                   |      |               |
|              |          | 20-29   | Gobo 2                                   |      |               |
|              |          | 30-39   | Gobo 3                                   |      |               |
|              |          | 40-49   | Gobo 4                                   |      |               |
|              |          | 50-59   | Gobo 5                                   |      |               |
|              |          | 60-69   | Gobo 6                                   |      |               |
|              |          | 70-77   | Gobo 7                                   |      |               |
|              |          | 78-93   | Gobo 1 shake, slow to fast               |      |               |
|              |          | 94-109  | Gobo 2 shake, slow to fast               |      |               |
|              |          | 110-125 | Gobo 3 shake, slow to fast               |      |               |
|              |          | 126-141 | Gobo 4 shake, slow to fast               |      |               |
|              |          | 142-157 | Gobo 5 shake, slow to fast               |      |               |
|              |          | 158-173 | Gobo 6 shake, slow to fast               |      |               |
|              |          | 174-189 | Gobo 7 shake, slow to fast               |      |               |
|              |          |         | <b>Scroll</b>                            |      |               |
|              |          | 190-221 | Clockwise scroll, fast → slow            |      |               |
|              |          | 222-223 | Stop                                     |      |               |
|              |          | 224-255 | Counter-clockwise scroll, slow → fast    |      |               |
| 12           | 17       |         | <b>Rotating Gobo Index/Rotation</b>      |      | 0             |
|              |          | 0-127   | Index Position                           |      |               |
|              |          |         | <b>Rotate</b>                            |      |               |
|              |          | 129-189 | Clockwise, fast → slow                   |      |               |
|              |          | 190-193 | Stop                                     |      |               |
| 13           | 18       |         | <b>Rotating Gobo Index/Rotation Fine</b> |      | 0             |
|              |          | 0-255   | Index position                           |      |               |
| 14           | 19       |         | <b>Fixed Gobo</b>                        | X    | 0             |
|              |          | 0-9     | Open                                     |      |               |
|              |          | 10-19   | Gobo 1                                   |      |               |
|              |          | 20-29   | Gobo 2                                   |      |               |
|              |          | 30-39   | Gobo 3                                   |      |               |
|              |          | 40-49   | Gobo 4                                   |      |               |
|              |          | 50-59   | Gobo 5                                   |      |               |
|              |          | 60-69   | Gobo 6                                   |      |               |
|              |          | 70-79   | Gobo 7                                   |      |               |
|              |          | 80-89   | Gobo 8                                   |      |               |
|              |          | 90-99   | Gobo 9                                   |      |               |
|              |          | 100-109 | Gobo 1 Shake, slow to fast               |      |               |
|              |          | 110-119 | Gobo 2 Shake, slow to fast               |      |               |
|              |          | 120-129 | Gobo 3 Shake, slow to fast               |      |               |
|              |          | 130-139 | Gobo 4 Shake, slow to fast               |      |               |
|              |          | 140-149 | Gobo 5 Shake, slow to fast               |      |               |
|              |          | 150-159 | Gobo 6 Shake, slow to fast               |      |               |
|              |          | 160-169 | Gobo 7 Shake, slow to fast               |      |               |
|              |          | 170-179 | Gobo 8 Shake, slow to fast               |      |               |
|              |          | 180-189 | Gobo 9 Shake, slow to fast               |      |               |

# ELATION PARAGON S - DMX TRAITS

Features subject to change without notice

| MODE/CHANNEL |          |         | FUNCTION                                    | SNAP | DEFAULT VALUE |
|--------------|----------|---------|---------------------------------------------|------|---------------|
| STANDARD     | EXTENDED | VALUES  |                                             |      |               |
| 14           | 19       |         | <b>Scroll</b>                               | X    | 0             |
|              |          | 190-221 | Clockwise, fast → slow                      |      |               |
|              |          | 222-223 | Stop                                        |      |               |
|              |          | 224-255 | Counter-clockwise, slow → fast              |      |               |
|              | 20       |         | <b>Fixed Gobo Fine</b>                      |      | 0             |
|              |          | 0-255   | Position                                    |      |               |
| 15           | 21       |         | <b>Rotating Prism 1</b>                     | X    | 0             |
|              |          | 0-63    | Open                                        |      |               |
|              |          | 64-255  | 4-facet                                     |      |               |
| 16           | 22       |         | <b>Rotating Prism 1 Index/Rotation</b>      |      | 0             |
|              |          | 0-127   | Index position                              |      |               |
|              |          |         | <b>Rotate</b>                               |      |               |
|              |          | 128-189 | Clockwise, fast → slow                      |      |               |
|              |          | 190-193 | Stop                                        |      |               |
|              |          | 194-255 | Counter-clockwise, slow → fast              |      |               |
|              | 23       |         | <b>Rotating Prism 1 Index/Rotation Fine</b> |      | 0             |
|              |          | 0-255   | Index position                              |      |               |
| 17           | 24       |         | <b>Rotating Prism 2</b>                     | X    | 0             |
|              |          | 0-63    | Open                                        |      |               |
|              |          | 64-255  | 4-facet linear                              |      |               |
| 18           | 25       |         | <b>Rotating Prism 2 Index/Rotation</b>      |      | 0             |
|              |          | 0-127   | Index position                              |      |               |
|              |          |         | <b>Rotate</b>                               |      |               |
|              |          | 128-189 | Clockwise, fast → slow                      |      |               |
|              |          | 190-193 | Stop                                        |      |               |
|              |          | 194-255 | Counter-clockwise, slow → fast              |      |               |
|              | 26       |         | <b>Rotating Prism 2 Index/Rotation Fine</b> |      | 0             |
|              |          | 0-255   | Index position                              |      |               |
| 19           | 27       |         | <b>Focus</b>                                |      | 127           |
|              |          | 0-255   | Infinity → Near                             |      |               |
| 20           | 28       |         | <b>Focus Fine</b>                           |      | 127           |
|              |          | 0-255   | Fine adjustment                             |      |               |
| 21           | 29       |         | <b>Zoom</b>                                 |      | 127           |
|              |          | 0-255   | Narrow → Wide                               |      |               |
| 22           | 30       |         | <b>Zoom Fine</b>                            |      | 127           |
|              |          | 0-255   | Fine adjustment                             |      |               |

# ELATION PARAGON S - DMX TRAITS

Features subject to change without notice

| MODE/CHANNEL |          |         | FUNCTION               | SNAP | DEFAULT VALUE |
|--------------|----------|---------|------------------------|------|---------------|
| STANDARD     | EXTENDED | VALUES  |                        |      |               |
|              |          |         | <b>Auto Focus</b>      |      |               |
|              |          | 0-4     | Auto Focus Off         |      |               |
|              |          | 5-9     | 5.0m                   |      |               |
|              |          | 10-14   | 5.2m                   |      |               |
|              |          | 15-19   | 5.4m                   |      |               |
|              |          | 20-24   | 5.6m                   |      |               |
|              |          | 25-29   | 5.8m                   |      |               |
|              |          | 30-34   | 6.0m                   |      |               |
|              |          | 35-39   | 6.3m                   |      |               |
|              |          | 40-44   | 6.5m                   |      |               |
|              |          | 45-49   | 6.8m                   |      |               |
|              |          | 50-54   | 7.0m                   |      |               |
|              |          | 55-59   | 7.3m                   |      |               |
|              |          | 60-64   | 7.5m                   |      |               |
|              |          | 65-69   | 7.7m                   |      |               |
|              |          | 70-74   | 8.0m                   |      |               |
|              |          | 75-79   | 8.3m                   |      |               |
|              |          | 80-84   | 8.5m                   |      |               |
|              |          | 85-89   | 8.7m                   |      |               |
|              |          | 90-94   | 9.0m                   |      |               |
|              |          | 95-99   | 9.3m                   |      |               |
|              |          | 100-104 | 9.5m                   |      |               |
|              | 31       | 105-109 | 9.8m                   |      | 0             |
|              |          | 110-114 | 10.0m                  |      |               |
|              |          | 115-119 | 10.5m                  |      |               |
|              |          | 120-124 | 11.0m                  |      |               |
|              |          | 125-129 | 11.5m                  |      |               |
|              |          | 130-134 | 12.0m                  |      |               |
|              |          | 135-139 | 12.5m                  |      |               |
|              |          | 140-144 | 13.0m                  |      |               |
|              |          | 145-149 | 13.5m                  |      |               |
|              |          | 150-154 | 14.0m                  |      |               |
|              |          | 155-159 | 14.5m                  |      |               |
|              |          | 160-164 | 15.0m                  |      |               |
|              |          | 165-169 | 15.5m                  |      |               |
|              |          | 170-174 | 16.0m                  |      |               |
|              |          | 175-179 | 16.5m                  |      |               |
|              |          | 180-184 | 17.0m                  |      |               |
|              |          | 185-189 | 17.5m                  |      |               |
|              |          | 190-194 | 18.0m                  |      |               |
|              |          | 195-199 | 18.5m                  |      |               |
|              |          | 200-204 | 19.0m                  |      |               |
|              |          | 205-209 | 19.5m                  |      |               |
|              |          | 210-214 | 20.0m                  |      |               |
|              |          | 215-255 | Idle                   |      |               |
|              | 32       |         | <b>Auto Focus Fine</b> |      | 0             |
|              |          | 0-255   | Fine adjustment        |      |               |

# ELATION PARAGON S - DMX TRAITS

Features subject to change without notice

| MODE/CHANNEL |          |         | FUNCTION                   | SNAP | DEFAULT VALUE |
|--------------|----------|---------|----------------------------|------|---------------|
| STANDARD     | EXTENDED | VALUES  |                            |      |               |
| 23           | 33       |         | <b>Shutter / Strobe</b>    | X    | 50            |
|              |          | 0-31    | Closed                     |      |               |
|              |          | 32-63   | Open                       |      |               |
|              |          | 64-95   | Strobe, slow → fast        |      |               |
|              |          | 96-127  | Open                       |      |               |
|              |          | 128-159 | Pulse effect               |      |               |
|              |          | 160-191 | Open                       |      |               |
|              |          | 192-223 | Random Strobe, slow → fast |      |               |
|              |          | 224-255 | Open                       |      |               |
| 24           | 34       |         | <b>Dimmer</b>              |      | 0             |
|              |          | 0-255   | Intensity 0 → 100%         |      |               |
| 25           | 35       |         | <b>Dimmer Fine</b>         |      | 0             |
|              |          | 0-255   | Fine adjustment            |      |               |
| 26           | 36       |         | <b>Dim Modes</b>           | X    | 0             |
|              |          | 0-20    | Standard                   |      |               |
|              |          | 21-40   | Stage                      |      |               |
|              |          | 41-60   | TV                         |      |               |
|              |          | 61-80   | Architectural              |      |               |
|              |          | 81-100  | Theatre                    |      |               |
|              |          | 101-120 | Stage 2                    |      |               |
|              |          |         | <b>Dimmer Delay Time</b>   |      |               |
|              |          | 121     | 0s                         |      |               |
|              |          | 122     | 0.1s                       |      |               |
|              |          | 123     | 0.2s                       |      |               |
|              |          | 124     | 0.3s                       |      |               |
|              |          | 125     | 0.4s                       |      |               |
|              |          | 126     | 0.5s                       |      |               |
|              |          | 127     | 0.6s                       |      |               |
|              |          | 128     | 0.7s                       |      |               |
|              |          | 129     | 0.8s                       |      |               |
|              |          | 130     | 0.9s                       |      |               |
|              |          | 131     | 1.0s                       |      |               |
|              |          | 132     | 1.5s                       |      |               |
|              |          | 133     | 2.0s                       |      |               |
|              |          | 134     | 3.0s                       |      |               |
|              |          | 135     | 4.0s                       |      |               |
|              |          | 136     | 5.0s                       |      |               |
|              |          | 137     | 6.0s                       |      |               |
|              |          | 138     | 7.0s                       |      |               |
|              |          | 139     | 8.0s                       |      |               |
|              |          | 140     | 9.0s                       |      |               |
|              |          | 141     | 10.0s                      |      |               |
|              |          | 142-255 | Idle                       |      |               |
| 27           | 37       |         | <b>Iris</b>                |      | 0             |
|              |          | 0-191   | Open → Close               |      |               |
|              |          | 192-223 | Pulse Closing, fast → slow |      |               |
|              |          | 224-255 | Pulse Opening, slow → fast |      |               |
|              | 38       |         | <b>Iris Fine</b>           |      | 0             |
|              |          | 0-255   | Fine adjustment            |      |               |

# ELATION PARAGON S - DMX TRAITS

| Features subject to change without notice |          |         |                                      |      |               |
|-------------------------------------------|----------|---------|--------------------------------------|------|---------------|
| MODE/CHANNEL                              |          |         | FUNCTION                             | SNAP | DEFAULT VALUE |
| STANDARD                                  | EXTENDED | VALUES  |                                      |      |               |
| 28                                        | 39       |         | <b>Frost 1 (Soft)</b>                |      | 0             |
|                                           |          | 0-255   | Open → Max                           |      |               |
| 29                                        | 40       |         | <b>Frost 2 (Wash)</b>                |      | 0             |
|                                           |          | 0-255   | Open → Max                           |      |               |
| 30                                        | 41       |         | <b>Animation Wheel</b>               |      | 0             |
|                                           |          | 0-7     | Open                                 |      |               |
|                                           |          | 8-255   | Min → Max                            |      |               |
|                                           |          |         | <b>Fixed Gobo Wheel 2 (Optional)</b> |      |               |
|                                           |          | 0-9     | Open                                 |      |               |
|                                           |          | 10-19   | Gobo 1                               |      |               |
|                                           |          | 20-29   | Gobo 2                               |      |               |
|                                           |          | 30-39   | Gobo 3                               |      |               |
|                                           |          | 40-49   | Gobo 4                               |      |               |
|                                           |          | 50-59   | Gobo 5                               |      |               |
|                                           |          | 60-69   | Gobo 6                               |      |               |
|                                           |          | 70-79   | Gobo 7                               |      |               |
|                                           |          | 78-93   | Gobo 1 Shake, slow to fast           |      |               |
|                                           |          | 94-109  | Gobo 2 Shake, slow to fast           |      |               |
|                                           |          | 110-125 | Gobo 3 Shake, slow to fast           |      |               |
|                                           |          | 126-141 | Gobo 4 Shake, slow to fast           |      |               |
|                                           |          | 142-157 | Gobo 5 Shake, slow to fast           |      |               |
|                                           |          | 158-173 | Gobo 6 Shake, slow to fast           |      |               |
|                                           |          | 174-189 | Gobo 7 Shake, slow to fast           |      |               |
|                                           |          |         | <b>Scroll</b>                        |      |               |
|                                           |          | 190-221 | Clockwise, fast → slow               |      |               |
|                                           |          | 222-223 | Stop                                 |      |               |
|                                           |          | 224-255 | Counter-clockwise, slow → fast       |      |               |
| 31                                        | 42       |         | <b>Animation Index</b>               |      | 64            |
|                                           |          | 0-127   | Position                             |      |               |
|                                           |          |         | <b>Scroll</b>                        |      |               |
|                                           |          | 128-189 | Clockwise, fast → slow               |      |               |
|                                           |          | 190-193 | Stop                                 |      |               |
|                                           |          | 194-255 | Counter-clockwise, slow → fast       |      |               |
|                                           |          |         | <b>Fixed Gobo 2 Fine (Optional)</b>  |      |               |
|                                           |          | 0-255   | Fine adjustment                      |      | 127           |
| 32                                        | 43       | 0-255   | <b>Blade 1A</b>                      |      | 0             |
|                                           |          |         | Open → Closed                        |      |               |
|                                           | 44       | 0-255   | <b>Blade 1A Fine</b>                 |      | 0             |
|                                           |          |         | Fine adjustment                      |      |               |
| 33                                        | 45       | 0-255   | <b>Blade 1B</b>                      |      | 0             |
|                                           |          |         | Open → Closed                        |      |               |
|                                           | 46       | 0-255   | <b>Blade 1B Fine</b>                 |      | 0             |
|                                           |          |         | Fine adjustment                      |      |               |
| 34                                        | 47       | 0-255   | <b>Blade 2A</b>                      |      | 0             |
|                                           |          |         | Open → Closed                        |      |               |
|                                           | 48       | 0-255   | <b>Blade 2A Fine</b>                 |      | 0             |
|                                           |          |         | Fine adjustment                      |      |               |
| 35                                        | 49       | 0-255   | <b>Blade 2B</b>                      |      | 0             |
|                                           |          |         | Open → Closed                        |      |               |
|                                           | 50       | 0-255   | <b>Blade 2B Fine</b>                 |      | 0             |
|                                           |          |         | Fine adjustment                      |      |               |

# ELATION PARAGON S - DMX TRAITS

Features subject to change without notice

| MODE/CHANNEL |          |         | FUNCTION                     | SNAP | DEFAULT VALUE |
|--------------|----------|---------|------------------------------|------|---------------|
| STANDARD     | EXTENDED | VALUES  |                              |      |               |
| 36           | 51       | 0-255   | <b>Blade 3A</b>              |      | 0             |
|              |          |         | Open → Closed                |      |               |
|              | 52       | 0-255   | <b>Blade 3A Fine</b>         |      | 0             |
|              |          |         | Fine adjustment              |      |               |
| 37           | 53       | 0-255   | <b>Blade 3B</b>              |      | 0             |
|              |          |         | Open → Closed                |      |               |
|              | 54       | 0-255   | <b>Blade 3B Fine</b>         |      | 0             |
|              |          |         | Fine adjustment              |      |               |
| 38           | 55       | 0-255   | <b>Blade 4A</b>              |      | 0             |
|              |          |         | Open → Closed                |      |               |
|              | 56       | 0-255   | <b>Blade 4A Fine</b>         |      | 0             |
|              |          |         | Fine adjustment              |      |               |
| 39           | 57       | 0-255   | <b>Blade 4B</b>              |      | 0             |
|              |          |         | Open → Closed                |      |               |
|              | 58       | 0-255   | <b>Blade 4B Fine</b>         |      | 0             |
|              |          |         | Fine adjustment              |      |               |
| 40           | 59       |         | <b>Framing Rotation</b>      |      | 127           |
|              |          | 0-126   | Min (-120°)                  |      |               |
|              |          | 127-128 | Parallel (0°)                |      |               |
|              |          | 129-255 | Max (+120°)                  |      |               |
|              | 60       |         | <b>Framing Rotation Fine</b> |      | 0             |
|              |          | 0-255   | Fine adjustment              |      |               |
|              | 61       |         | <b>Framing Macro Speed</b>   |      | 0             |
|              |          | 0-255   | Max → Min Speed              |      |               |
|              | 62       |         | <b>Framing Macro</b>         | X    | 0             |
|              |          | 0-7     | Off                          |      |               |
|              |          | 8-15    | Macro 1                      |      |               |
|              |          | 16-23   | Macro 2                      |      |               |
|              |          | 24-31   | Macro 3                      |      |               |
|              |          | 32-39   | Macro 4                      |      |               |
|              |          | 40-47   | Macro 5                      |      |               |
|              |          | 48-55   | Macro 6                      |      |               |
|              |          | 56-63   | Macro 7                      |      |               |
|              |          | 64-71   | Macro 8                      |      |               |
|              |          | 72-79   | Macro 9                      |      |               |
|              |          | 80-87   | Macro 10                     |      |               |
|              |          | 88-95   | Macro 11                     |      |               |
|              |          | 96-103  | Macro 12                     |      |               |
|              |          | 104-111 | Macro 13                     |      |               |
|              |          | 112-119 | Macro 14                     |      |               |
|              |          | 120-127 | Macro 15                     |      |               |
|              |          | 128-135 | Macro 16                     |      |               |
|              |          | 136-143 | Macro 17                     |      |               |
|              |          | 144-151 | Macro 18                     |      |               |
|              |          | 152-159 | Macro 19                     |      |               |
|              |          | 160-167 | Macro 20                     |      |               |
|              |          | 168-175 | Macro 21                     |      |               |
|              |          | 176-183 | Macro 22                     |      |               |
|              |          | 184-191 | Macro 23                     |      |               |
|              |          | 192-199 | Macro 24                     |      |               |

# ELATION PARAGON S - DMX TRAITS

Features subject to change without notice

| MODE/CHANNEL |          |         | FUNCTION                                              | SNAP | DEFAULT VALUE |
|--------------|----------|---------|-------------------------------------------------------|------|---------------|
| STANDARD     | EXTENDED | VALUES  |                                                       |      |               |
|              | 62       |         | <b>Framing Macro (continued)</b>                      | X    | 0             |
|              |          | 200-207 | Macro 25                                              |      |               |
|              |          | 208-215 | Macro 26                                              |      |               |
|              |          | 216-223 | Macro 27                                              |      |               |
|              |          | 224-231 | Macro 28                                              |      |               |
|              |          | 232-239 | Macro 29                                              |      |               |
|              |          | 240-247 | Macro 30                                              |      |               |
|              |          | 248-255 | Macro 31                                              |      |               |
|              | 63       |         | <b>Pan/Tilt Speed</b>                                 | X    | 0             |
|              |          | 0-225   | Max → Min Speed                                       |      |               |
|              |          | 226-235 | Blackout by movement                                  |      |               |
|              |          | 236-245 | Blackout by wheel changes                             |      |               |
| 41           | 64       |         | <b>Control</b>                                        | X    | 0             |
|              |          | 0-19    | Wheel Snap                                            |      |               |
|              |          | 20-29   | Color Wheel Fade                                      |      |               |
|              |          | 30-39   | Color/Gobo Wheel Fade                                 |      |               |
|              |          |         | <b>Fan Mode</b>                                       |      |               |
|              |          | 40-44   | Mute                                                  |      |               |
|              |          | 45-49   | Studio                                                |      |               |
|              |          | 50-59   | Low                                                   |      |               |
|              |          | 60-69   | High                                                  |      |               |
|              |          | 70-79   | Auto (default)                                        |      |               |
|              |          |         | <b>Reset</b>                                          |      |               |
|              |          | 80-84   | Fixture                                               |      |               |
|              |          | 85-87   | Pan Tilt                                              |      |               |
|              |          | 88-90   | Color                                                 |      |               |
|              |          | 91-93   | Gobo                                                  |      |               |
|              |          | 94-96   | Focus Zoom                                            |      |               |
|              |          | 97-99   | Other Features                                        |      |               |
|              |          |         | <b>Refresh Rate (Hz)</b>                              |      |               |
|              |          | 100-168 | Refresh Rate (900Hz - 25KHz), see Refresh Rates Table |      |               |
|              |          | 169-170 | Ultra Dimming - 25 KHz (default)                      |      |               |
|              |          | 171     | CMY Smooth                                            |      |               |
|              |          | 172     | CMY Fast (default)                                    |      |               |
|              |          | 173-174 | Hibernation Off                                       |      |               |
|              |          | 175-176 | Hibernation                                           |      |               |
|              |          | 177-178 | Sun Protection On (default)                           |      |               |
|              |          | 179-180 | Sun Protection Off                                    |      |               |
|              |          | 181-190 | Pan Tilt Smooth                                       |      |               |
|              |          | 191-200 | Pan Tilt Fast (default)                               |      |               |



# ELATION PARAGON S - DMX TRAITS

Features subject to change without notice

| MODE/CHANNEL |          |         | FUNCTION                                                                                 | SNAP | DEFAULT VALUE |
|--------------|----------|---------|------------------------------------------------------------------------------------------|------|---------------|
| STANDARD     | EXTENDED | VALUES  |                                                                                          |      |               |
| 41           | 64       |         | <b>Dimmer Curve</b>                                                                      | X    | 0             |
|              |          | 201-210 | Linear                                                                                   |      |               |
|              |          | 211-220 | Square                                                                                   |      |               |
|              |          | 221-230 | Inverse Square                                                                           |      |               |
|              |          | 231-240 | S-Curve (default)                                                                        |      |               |
|              |          |         | <b>Color Smoothing</b>                                                                   |      |               |
|              |          | 241-242 | Color Smoothing Disabled (default)                                                       |      |               |
|              |          | 243-244 | Color Smoothing Enabled                                                                  |      |               |
|              |          |         | <b>Theater Mode</b> (automatically activated when Mute or Studio fan modes are selected) |      |               |
|              |          | 245-246 | Fastest Speeds (default)                                                                 |      |               |
|              |          | 247-249 | Quiet Speeds                                                                             |      |               |
|              |          | 250-251 | Display Off                                                                              |      |               |
|              |          | 252-253 | Display On (default)                                                                     |      |               |
|              |          | 254-255 | Idle                                                                                     |      |               |